

## Mounting Instruction proDOME175/240®

The concrete built-in pot [proDOME175®](#) and [proDOME240®](#) can be used for installation in exposed concrete and plaster by means of three different types of installation (see below).

The **two-part** concrete built-in pot consists of a lid/ring and bottom:



### Assembly

1. Turn the lid/ring upside down and place it on a stable surface to optimally stake the bottom.
2. Turn the bottom upside down and press with your hand (it may require a light bump). Make sure that the lid/ring is completely locked in place in the bottom.

1.



2.



### Types of installation for exposed concrete, as well as plaster

- 3.A Mounting on reinforcing bars in the back with wires through the 6 fastening straps
- 3.B Mounting on formwork board in front with a nail through the central hole

3.A



3.A/B



3.B



### Mounting method for plaster

- 3.C Mounting on formwork board in front with nails through the 6 mounting holes

3.C



3.C



### Cable/Pipe inlet

4. Drill holes at the desired points, depending on the cable/pipe diameter.